

EVA GUI for website

Rev

	RS-232 and RS-485	IEEE (GPIB)	USB	LAN
EVA Control GUI 1.0.0	+	N/A	N/A	N/A

- 1. LVRTE2010 std
- 2. visa520runtime

<http://www.ni.com/download/labview-run-time-engine-2010/2087/en/>
<http://www.ni.com/download/ni-visa-run-time-engine-5.2/3342/en/>

Required be installed for: RS232/485
Required be installed for: RS232/485

Definition:

EVA Control GUI

"Soft Front Panel" program to demonstrate remote programming capabilities of the EVA™ power supplies.